

# iGuide Quick Guide



**Quick Menu: Quick And Easy...**  
The **Quick Menu** offers shortcuts to key **i-Guide** features. Just press the **MENU** from anywhere in the guide — or even while you're watching a program — and you'll have access to features like the **Search**, **Favorites**, **Parental Controls** and more.

Press the **MENU** on your remote to highlight an option, press **OK** and you're on your way.

## Program Information At Your Fingertips

**i-Guide** provides **Instant Information** while you view program listings, including program title, start/end time, program rating, a brief program description and helpful indicators that identify your settings, such as **Reminders**, **Recordings** and **Favorites**.

Press **MENU** button twice for the **Main Menu**.



## All Access With Main Menu.

**Main Menu\*** gives you easy access to all features. Simply press **MENU** twice, then select from the options available, including **TV Listings By Time**, viewing options by category, **Parental Controls**, **Favorites**, **Local Weather** and more.



## Enhanced Searching.

With **i-Guide**, you can sort and view program **Listings By Time**, **Listings By Channel**, or by categories such as **Movies**, **Sports**, **Kids** and more. Select a category from the **Main Menu** or **Quick Menu** to display listings.



## Smart Channel Surfing.

The **Flip Bar** lets you see program information as you change channels.

When you find a program you like, press **OK** to make the **Flip Bar** disappear or press **INFO** for more program details.



Subcategories let you focus your search even further. For example, you can search for movies that fit your mood: comedies, dramas, adventure and more.



## Easy-To-Understand Listings.

**TV Listings** appear in a grid format with channel numbers and network call letters down the left side and times along the top. Listings are color coded to help you identify different types of programs.

- Blue** – Regular programs
- Purple** – Movies
- Green** – Sports
- Light Blue** – Children's programs

For more detailed information, press the **INFO** button on your remote.



## Action Icon Shortcuts.

From the Program Information screen, you can use the **Action Icons** at the bottom of the screen to set a **Reminder**, see other air times and more.

Use the arrow **Left/Right** buttons to highlight an icon, a description will appear just below the icons.



The **Mini Guide** lets you watch television and view listings without having to leave your program. To access, press **OK** or **INFO** then use the **Left/Right** buttons to browse time and use the **Up/Down** buttons to browse channels.



## Parental Controls To Protect Your Family.

**Parental Controls** let you restrict viewing and purchases of TV programming based on your preferences. Set a personalized 4-digit **PIN** and you can place locks on selected ratings, channels and titles. You can also hide adult titles from being displayed on screen.

Select **Parental Controls** from the **Quick Menu** to set up **Parental Controls and PINs**.



## Go Ahead, Play Favorites.

**i-Guide's Favorites** feature lets you quickly access the channels you've designated as your **Favorites**. Just select **Favorites** from the **Main Menu** or **Quick Menu**.